



3651 N Highway 89 • Chino Valley, AZ 86323
 (928) 636-7080 • www.p-a-g.net

MULTI-LIGHT MOUNT INSTALLATION INSTRUCTIONS ALL KIT # 87011

Fits all ORF Rock Slider Front Bumpers
 (Kits # 83095, 83096, 83200, 83201)



Before starting installation

NOTE
 Kit parts are prefaced by the word **kit** and appear in **bold** print.

- Carefully read all warnings and instructions completely before beginning.
- Verify all parts have been received in this kit by checking the parts list at the end of this document.

NOTE
 If parts are missing from kit, please be prepared to provide the following information:

- Name** of purchase location
- Bar Code** on side of box
- Date** above bar code
- Date** inside box cover
- Inspector #** from inside box cover

- Only install this kit on the vehicle for which it is specified. If anytime during the installation you encounter something different from what is outlined in the instructions, call technical support at (928) 636-7080.

Install kit

- Install kit **mount** (multi-light) on ORF front bumper with four kit **bolts** (7/16" x 1") and kit **washers** (3/8" USS).



NOTE
 You can install a Hi-Lift jack along with the kit **mount**, but you must use longer bolts.

Accessories

The following accessory is also available:
Kit # 83100: Rock Slider Rear Bumper (TJ, TJL, YJ)

Parts list

<u>Qty.</u>	<u>Description</u>
4	Bolt , 7/16" x 1"
1	Mount , multi-light
4	Washer , 3/8" USS

Rev. 01, Copyright 07/06
 Performance Automotive Group
 www.p-a-g.net